

Load the trailer,
brakes released,
read the weights –
It's that easy!

Put yourself ahead of the competition

- ✓ Maximize payloads for the highest profits
- ✓ Eliminate checkweighing
- ✓ Avoid overweight citations
- ✓ Extend trailer life by protecting from overloading
- ✓ Boost driver confidence with PIN protection of calibration

With LoadMaxx tractor and trailer scales, Air-Weigh has just the right scale for your application.

Air-Weigh

CORPORATE OFFICES
1730 WILLOW CREEK CIRCLE
EUGENE, OR 97402

WEBSITE
www.air-weigh.com

TOLL-FREE SALES
(888) 459-3444

Air-Weigh



MAXIMUM LOAD MINIMUM EFFORT

LOADMAXX TRAILER SCALES

Choose the Air-Weigh Trailer Scale that's right for your application

Air-Weigh Scales Feature

- Dual-point calibration for accuracy at all weights
- High precision pressure sensor measures fractions of one PSI
- Compensates for temperature and altitude
- Tested operating temperature -40°F to 185°F
- Displays weight in 20 lb or kg increments
- Accurate to within 300 lbs of a DOT-certified scale
- Factory calibration built in for most popular suspension models
- Provides PIN protection of calibration
- Trailer scale in rugged outdoor trailer display – no mounting box required
- Languages: English, Spanish and French
- Tested to stringent SAE commercial vehicle standards

3-year Limited Warranty

LoadMaxx with ComLink

- All of the same scale features as the Base Model, but allows the trailer scale to communicate weights via multiplexing to the tractor scale
- Enables drivers to view steer, drive, trailer, GVW and net payload weights on in-cab display
- Tractor/trailer weight information can also be sent to back-office software via communications interface
- Automatic drop and hook capabilities – calibration stored in trailer scale
- Use NET Payload feature to determine cargo/product weight that has been loaded or offloaded
- Include the trailer, GVW and net payload weights when printing time/date stamped weight tickets using the optional printer
- Heavy Haul: Up to 7 trailer scale weights in a single heavy haul configuration will display individually on the in-cab display
- Simple plug-and-play ComLink upgrade available even after installation of Base Model



Add the LoadMaxx Tractor Scale for tractor axle weights in cab

- Automatically reads and displays weight of trailers equipped with LoadMaxx and ComLink
- Has the ability to transmit weights to the tractor's data bus
- Bluetooth communication to LoadMaxx smartphone App



LoadMaxx Base Model

- Easily upgraded to the communication model
- Ideal for applications that don't require trailer weights in cab
- Economical standalone trailer scale that doesn't skimp on premium features
- Same accuracy as LoadMaxx with ComLink
- Driver friendly, icon based, touch screen display
- LoadMaxx trailer scales now provide the option to store up to four manual calibrations
 - For example, a tandem trailer with a liftable axle can have two calibrations- one with all axles down and one with the liftable axle up
- Built-in LED lights alert when user-set warning and target weight thresholds are reached



LoadMaxx trailer scale for mechanical suspensions

- Patented deflection sensor technology measures axle flex with weight transfer
- For OEM and retrofit applications



Join the extensive family of satisfied Air-Weigh on-board scale customers.

Ask your trailer representative to include Air-Weigh scales on your new trailers. Available as standard equipment or as a factory option with more than 175 trailer manufacturers, and growing.